



NOTE: Locate surge arrester module as close to VW sensor as possible.  
 For borehole applications locate surge arrester module at top of borehole.