F.A.P. Plus™ Pump

1. Description

2. Installation

1. Description

How does it work?



Discharge Phase



Intake Phase



Inside a well …



❶

Product level above filter

Product pumped through the by-pass

By-pass

Hydrophobic Filter

Product/ water interface

Float


1
2
Product level at filter
Product pumped through the hydrophobic filter


1
2
3
Water level rose more than coiled hose can accommodate
WATER pumped through the by-pass

Typical Installation



Typical Installation

Well Clincher



Typical Installation



F.A.P. Pump





Standard Skimmer



Typical Installation

Optional Skimmers

Density Skimmer



High Viscosity Skimmer

Typical Installation

Filter/Regulator



Typical Installation



Overfill Protection Device

Product Storage Tank

Typical Installation

Air Compressor(s)



1. Description

2. Installation

Unpacking
and coffee break

Setting Depth